



CONCESIONARIO OFICIAL SANTANA

SANTANA - 35121-72600 - CONJ FARO PRINCIPAL

Conjunto faro principal

UNIT, LAMP

UNITÉ, LAMPE

Vehículo ??dificación

Samurai/SJ SJ410P-4 (E01) SJ410P

Samurai/SJ SJ410V-2 SJ410V

Samurai/SJ SJ410V-3 (E01) SJ410V

Samurai/SJ SJ410V-4 (E01) SJ410V

Alto - A-Star/Celerio/800/Fronte SS80-2

Alto - A-Star/Celerio/800/Fronte SS80F

Carry/Supercarry/Every ST90V ST90V

Samurai/SJ SJ410W (E01)

Samurai/SJ SJ413K-3 (E01)

Samurai/SJ SJ413Q-4/SJ413V-4/SJ413W-4 (E01)

Samurai/SJ SJ410/SJ410Q (E02,E15,E18,E19,E22,E25,E34,E39,E46)

Samurai/SJ SJ410-5 (E01) SJ410

Samurai/SJ SJ410K-2 SJ410K

Samurai/SJ SJ410W-2 (E01)

Samurai/SJ SJ413P-2 (E01)

Samurai/SJ SJ413W-3 (E01)

Carry/Supercarry/Every SK410-3 (E01)

Samurai/SJ SJ410P-3 (E01) SJ410P

Samurai/SJ SJ413V (E01)

Alto - A-Star/Celerio/800/Fronte SS80

Carry/Supercarry/Every ST90V-2 ST90V

LJ80 LJ81K-2/LJ81P-2

Samurai/SJ SJ410V (E01) SJ410V

Samurai/SJ SJ413V-3 (E01)

Samurai/SJ SJ410-2 SJ410

Samurai/SJ SJ410K-5 (E01) SJ410K

Samurai/SJ SJ410P-5 (E01) SJ410P

Samurai/SJ SJ413P-3 (E01)

Samurai/SJ SJ413W-2 (E01)

Samurai/SJ SJ410K (E02,E15,E18,E19,E22,E25,E34,E39,E46)

Samurai/SJ SJ410K-3 (E01) SJ410K
Samurai/SJ SJ410Q-4 (E01) SJ410Q
Alto - A-Star/Celerio/800/Fronte SS80F-2/SS80AF-2
Samurai/SJ SJ410V (E02,E06,E15,E16,E18,E19,E22,E25,E34,E39,E46,E54,E98)
Samurai/SJ SJ413Q (E01)
Samurai/SJ SJ413Q-2 (E01)
Samurai/SJ SJ410 (E01) SJ410
Carry/Supercarry/Every SK408-2
Samurai/SJ SJ410-3 (E01) SJ410
Samurai/SJ SJ413K (E01)
Samurai/SJ SJ413Q-3 (E01)
Samurai/SJ SJ410-4 (E01) SJ410
Samurai/SJ SJ410K/SJ410P (E01:TYPE 2)
Samurai/SJ SJ413V-2 (E01)
Carry/Supercarry/Every SK408
Samurai/SJ SJ410K (E02,E06,E15,E16,E18,E19,E22,E25,E34,E39,E46,E54,E98)
Samurai/SJ SJ410V (E02,E15,E18,E19,E22,E25,E34,E39,E46)
Samurai/SJ SJ413-3 (E01)
Samurai/SJ SJ413P (E01)
Samurai/SJ SJ410/SJ410Q/SJ410V (E01:TYPE 1)
Carry/Supercarry/Every ST90-3 ST90
Carry/Supercarry/Every ST90K-2 ST90K
Samurai/SJ SJ410Q (E01) SJ410Q
Samurai/SJ SJ410Q-2 SJ410Q
Samurai/SJ SJ410Q-3 (E01) SJ410Q
Samurai/SJ SJ410W-5 (E01) SJ410W
Samurai/SJ SJ413Q-5/SJ413V-5 (E01)
Samurai/SJ SJ410K-4 (E01) SJ410K
Samurai/SJ SJ410K/SJ410P (E01:TYPE 1)
Samurai/SJ SJ410Q-5 (E01) SJ410Q
Samurai/SJ SJ410V-5 (E01) SJ410V
Samurai/SJ SJ413Q-7/SJ413V-7 (E01)
Samurai/SJ SJ410/SJ410Q/SJ410V (E01:TYPE 2)
Carry/Supercarry/Every ST90K ST90K
Samurai/SJ SJ410K (E01) SJ410K
Samurai/SJ SJ413Q-6/SJ413V-6 (E01)
Carry/Supercarry/Every SK410 (E01)
Samurai/SJ SJ410P SJ410P
Samurai/SJ SJ410P-2 SJ410P
Samurai/SJ SJ410W-3 (E01) SJ410W
Carry/Supercarry/Every ST90-2 ST90
Samurai/SJ SJ410W-4 (E01) SJ410W
Samurai/SJ SJ413-2 (E01)
Samurai/SJ SJ413K-2 (E01)
LJ80 LJ80-2/LJ80Q-2/LJ80V-2
Samurai/SJ SJ413 (E01)
Samurai/SJ SJ413W (E01)
Carry/Supercarry/Every ST90 ST90

Carry/Supercarry/Every ST90K-3 ST90K


Carry/Supercarry/Every ST90V-3 ST90V

Samurai/SJ SJ410/SJ410Q (E02,E06,E15,E16,E18,E19,E22,E25,E34,E39,E46,E54,E98)

Carry/Supercarry/Every SK410-2 (E01)

FIG. 47

F - 11



SS80G/V E1