



SANTANA - 79100-63850 - CORCHETE

Corchete

HOOK SET

ENSEMBLE DE CROCHETS

Marca Referencia

Suzuki 7910063850

Vehículo

Samurai/SJ SJ410K-3/SJ410P-3 (E24)

Samurai/SJ SJ410P-4 (E01) SJ410P

Samurai/SJ SJ410V-2 SJ410V

Samurai/SJ SJ410V-3 (E01) SJ410V

Samurai/SJ SJ410V-4 (E01) SJ410V

Samurai/SJ SJ413/SJ413Q/SJ413V (E24)

Samurai/SJ SJ410W (E01)

Samurai/SJ SJ413K-3 (E01)

Samurai/SJ SJ413W-2 (E24)

Samurai/SJ SJ410/SJ410Q (E02,E15,E18,E19,E22,E25,E34,E39,E46)

Samurai/SJ SJ410-5 (E01) SJ410

Samurai/SJ SJ410K-2 SJ410K

Samurai/SJ SJ410W-2 (E01)

Samurai/SJ SJ413K (E28)

Samurai/SJ SJ413P-2 (E01)

Samurai/SJ SJ413W-3 (E01)

Samurai/SJ SJ410P-3 (E01) SJ410P

Samurai/SJ SJ413K-2/SJ413P-2 (E24)

Samurai/SJ SJ413V (E01)

Samurai/SJ SJ413 (E03,E33:MY 1988) 88 MODEL

Samurai/SJ SJ410K (E28:MY 1984) SJ410K 84 MODEL

Samurai/SJ SJ410V (E01) SJ410V

Samurai/SJ SJ410V (E28:MY 1982) SJ410V 82 MODEL

Samurai/SJ SJ413K/SJ413P (E24)

Samurai/SJ SJ413V-3 (E01)


Samurai/SJ SJ410-2 SJ410

Samurai/SJ SJ410K-5 (E01) SJ410K
Samurai/SJ SJ410P-5 (E01) SJ410P
Samurai/SJ SJ413-3/SJ413Q-3/SJ413V-3 (E24)
Samurai/SJ SJ413P-3 (E01)
Samurai/SJ SJ413W-2 (E01)
Samurai/SJ SJ410-3/SJ410Q-3/SJ410V-3 (E24)
Samurai/SJ SJ410K (E02,E15,E18,E19,E22,E25,E34,E39,E46)
Samurai/SJ SJ410K-3 (E01) SJ410K
Samurai/SJ SJ410W (E28:MY 1984) SJ410W 84 MODEL
Samurai/SJ SJ413W-3 (E24)
Samurai/SJ SJ410Q-4 (E01) SJ410Q
Samurai/SJ SJ410V (E28:MY 1984) SJ410V 84 MODEL
Samurai/SJ SJ410/SJ410Q (E28:MY 1983) 83 MODEL
Samurai/SJ SJ413 (E03,E33:MY 1986) 86 MODEL
Samurai/SJ SJ410V (E02,E06,E15,E16,E18,E19,E22,E25,E34,E39,E46,E54,E98)
Samurai/SJ SJ413/SJ413Q (E28)
Samurai/SJ SJ413K-3/SJ413P-3 (E24)
Samurai/SJ SJ413Q (E01)
Samurai/SJ SJ413Q-2 (E01)
Samurai/SJ SJ413V (E28)
Samurai/SJ SJ410 (E01) SJ410
Samurai/SJ SJ410-3 (E01) SJ410
Samurai/SJ SJ410-4/SJ410Q-4/SJ410V-4 (E24)
Samurai/SJ SJ413-2/SJ413Q-2/SJ413V-2 (E24)
Samurai/SJ SJ413K (E01)
Samurai/SJ SJ413Q-3 (E01)
Samurai/SJ SJ410-4 (E01) SJ410
Samurai/SJ SJ410K/SJ410P (E01:TYPE 2)
Samurai/SJ SJ410Q-5/SJ410V-5 (E24)
Samurai/SJ SJ410V (E28:MY 1983) SJ410V 83 MODEL
Samurai/SJ SJ410W (E28:MY 1983) SJ410W 83 MODEL
Samurai/SJ SJ413V-2 (E01)
Samurai/SJ SJ410K (E02,E06,E15,E16,E18,E19,E22,E25,E34,E39,E46,E54,E98)
Samurai/SJ SJ410V (E02,E15,E18,E19,E22,E25,E34,E39,E46)
Samurai/SJ SJ413 (Santana) (E01)
Samurai/SJ SJ413-3 (E01)
Samurai/SJ SJ413P (E01)
Samurai/SJ SJ410/SJ410Q (E28:MY 1984) 84 MODEL
Samurai/SJ SJ410/SJ410Q/SJ410V (E01:TYPE 1)
Samurai/SJ SJ410K (E28:MY 1982) SJ410K 82 MODEL
Samurai/SJ SJ410Q (E01) SJ410Q
Samurai/SJ SJ410Q-2 SJ410Q
Samurai/SJ SJ410Q-3 (E01) SJ410Q
Samurai/SJ SJ410W-5 (E01) SJ410W
Samurai/SJ SJ410K-4 (E01) SJ410K
Samurai/SJ SJ410K-5/SJ410P-5 (E24)
Samurai/SJ SJ410K/SJ410P (E01:TYPE 1)
Samurai/SJ SJ410Q-5 (E01) SJ410Q

Samurai/SJ SJ410V-5 (E01) SJ410V
Samurai/SJ SJ413W (E28)
Samurai/SJ SJ410/SJ410Q/SJ410V (E01:TYPE 2)
Samurai/SJ SJ413 (E03,E33:MY 1987) 87 MODEL
Samurai/SJ SJ410K (E01) SJ410K
Samurai/SJ SJ410K-4/SJ410P-4 (E24)
Samurai/SJ SJ410K (E28:MY 1983) SJ410K 83 MODEL
Samurai/SJ SJ410P SJ410P
Samurai/SJ SJ410P-2 SJ410P
Samurai/SJ SJ410W-3 (E01) SJ410W
Samurai/SJ SJ410W-4 (E01) SJ410W
Samurai/SJ SJ413-2 (E01)
Samurai/SJ SJ413K-2 (E01)
Samurai/SJ SJ410/SJ410Q (E28:MY 1982) 82 MODEL
Samurai/SJ SJ413 (E01)
Samurai/SJ SJ413W (E01)
Samurai/SJ SJ410/SJ410Q (E02,E06,E15,E16,E18,E19,E22,E25,E34,E39,E46,E54,E98)
Samurai/SJ SJ410W-3 (E24)
Samurai/SJ SJ413W (E24)
Jimny
Jimny

FIG.109

B - 12



SJ410 E1