



CONCESIONARIO OFICIAL SANTANA

SANTANA - 09250-02001 - TAPÓN AGUJERO ANTENA

Tapon agujero antena

CAP, ANTENNA HOLE

CAPUCHON, TROU D'ANTENNE

TAPPO, FORO ANTENNA

KAPPE, ANTENNENLOCH

Marca Referencia

Suzuki 0925002001

Vehículo

Samurai/SJ SJ410K-3/SJ410P-3 (E24)

Samurai/SJ SJ410P-4 (E01) SJ410P

Samurai/SJ SJ410V-2 SJ410V

Samurai/SJ SJ410V-3 (E01) SJ410V

Samurai/SJ SJ410V-4 (E01) SJ410V

Samurai/SJ SJ413 (E03,E33:MY 1994) 94 MODEL

Samurai/SJ SJ413-MIL (Santana)

Samurai/SJ SJ413/SJ413Q/SJ413V (E24)

Samurai/SJ SJ413V-7 (E24)

Samurai/SJ SJ413W-4 (E24)

Carry/Supercarry/Every SK410-4

Alto - A-Star/Celerio/800/Fronte SS80-2

Alto - A-Star/Celerio/800/Fronte SS80F

Carry/Supercarry/Every ST90V ST90V

Samurai/SJ SJ410W (E01)

Samurai/SJ SJ413K-3 (E01)

Samurai/SJ SJ413Q-4/SJ413V-4/SJ413W-4 (E01)

Samurai/SJ SJ413W-2 (E24)

Samurai/SJ SJ410/SJ410Q (E02,E15,E18,E19,E22,E25,E34,E39,E46)

Samurai/SJ SJ413 (E03,E33:MY 1988 1/2)

Samurai/SJ SJ410-5 (E01) SJ410

Samurai/SJ SJ410K-2 SJ410K

Samurai/SJ SJ410W-2 (E01)

Samurai/SJ SJ413 (Santana) (E22)

Samurai/SJ SJ413K (E28)

Samurai/SJ SJ413P-2 (E01)
Samurai/SJ SJ413W-3 (E01)
Samurai/SJ SJ413 (E03,E33:MY 1990) 90 MODEL
Carry/Supercarry/Every SK410-3 (E01)
Alto - A-Star/Celerio/800/Fronte SS80V
Samurai/SJ SJ410P-3 (E01) SJ410P
Samurai/SJ SJ413-8
Samurai/SJ SJ413K-2/SJ413P-2 (E24)
Samurai/SJ SJ413V (E01)
Sierra MG410/MG410W
Samurai/SJ SJ413 (E03,E33:MY 1988) 88 MODEL
Samurai/SJ SJ413 (E03,E33:MY 1991) 91 MODEL
Alto - A-Star/Celerio/800/Fronte SS80
Carry/Supercarry/Every ST90V-2 ST90V
Samurai/SJ SJ410K (E28:MY 1984) SJ410K 84 MODEL
Samurai/SJ SJ410V (E01) SJ410V
Samurai/SJ SJ410V (E28:MY 1982) SJ410V 82 MODEL
Samurai/SJ SJ413-9
Samurai/SJ SJ413K/SJ413P (E24)
Samurai/SJ SJ413V-3 (E01)
Samurai/SJ SJ410-2 SJ410
Samurai/SJ SJ410K-5 (E01) SJ410K
Samurai/SJ SJ410P-5 (E01) SJ410P
Samurai/SJ SJ413-3/SJ413Q-3/SJ413V-3 (E24)
Samurai/SJ SJ413P-3 (E01)
Samurai/SJ SJ413W-2 (E01)
Samurai/SJ SJ410-3/SJ410Q-3/SJ410V-3 (E24)
Samurai/SJ SJ410K (E02,E15,E18,E19,E22,E25,E34,E39,E46)
Samurai/SJ SJ410K-3 (E01) SJ410K
Samurai/SJ SJ410W (E28:MY 1984) SJ410W 84 MODEL
Samurai/SJ SJ413W-3 (E24)
Samurai/SJ SJ413 (E03,E33:MY 1989) 89 MODEL
Samurai/SJ SJ410Q-4 (E01) SJ410Q
Samurai/SJ SJ410V (E28:MY 1984) SJ410V 84 MODEL
Samurai/SJ SJ413Q-7 (E24)
Samurai/SJ SJ410/SJ410Q (E28:MY 1983) 83 MODEL
Samurai/SJ SJ413 (E03,E33:MY 1986) 86 MODEL
Alto - A-Star/Celerio/800/Fronte SS80F-2/SS80AF-2
Alto - A-Star/Celerio/800/Fronte SS80VX-3/SS80AV-3/SS80AVX-3
Samurai/SJ SJ410V (E02,E06,E15,E16,E18,E19,E22,E25,E34,E39,E46,E54,E98)
Samurai/SJ SJ413/SJ413Q (E28)
Samurai/SJ SJ413K-3/SJ413P-3 (E24)
Samurai/SJ SJ413Q (E01)
Samurai/SJ SJ413Q-2 (E01)
Samurai/SJ SJ413V (E28)
Samurai/SJ SJ410 (E01) SJ410
Carry/Supercarry/Every SK408-2
Samurai/SJ SJ410-3 (E01) SJ410

Samurai/SJ SJ410-4/SJ410Q-4/SJ410V-4 (E24)
Samurai/SJ SJ413-2/SJ413Q-2/SJ413V-2 (E24)
Samurai/SJ SJ413K (E01)
Samurai/SJ SJ413Q-3 (E01)
Samurai/SJ SJ410-4 (E01) SJ410
Samurai/SJ SJ410K/SJ410P (E01:TYPE 2)
Carry/Supercarry/Every SK410-2 (E24)
Samurai/SJ SJ410Q-5/SJ410V-5 (E24)
Samurai/SJ SJ410V (E28:MY 1983) SJ410V 83 MODEL
Samurai/SJ SJ410W (E28:MY 1983) SJ410W 83 MODEL
Samurai/SJ SJ413Q-4/SJ413V-4 (E24)
Samurai/SJ SJ413V-2 (E01)
Carry/Supercarry/Every SK408
Carry/Supercarry/Every SK410 (E24)
Carry/Supercarry/Every SK410-3 (E24)
Samurai/SJ SJ410K (E02,E06,E15,E16,E18,E19,E22,E25,E34,E39,E46,E54,E98)
Samurai/SJ SJ410V (E02,E15,E18,E19,E22,E25,E34,E39,E46)
Samurai/SJ SJ413 (E03,E33:MY 1993) 93 MODEL
Samurai/SJ SJ413 (Santana) (E01)
Samurai/SJ SJ413-3 (E01)
Samurai/SJ SJ413P (E01)
Samurai/SJ SJ410/SJ410Q (E28:MY 1984) 84 MODEL
Samurai/SJ SJ410/SJ410Q/SJ410V (E01:TYPE 1)
Alto - A-Star/Celerio/800/Fronte SS80V-2
Samurai/SJ SJ410K (E28:MY 1982) SJ410K 82 MODEL
Samurai/SJ SJ410Q (E01) SJ410Q
Samurai/SJ SJ410Q-2 SJ410Q
Samurai/SJ SJ410Q-3 (E01) SJ410Q
Samurai/SJ SJ410W-5 (E01) SJ410W
Samurai/SJ SJ413Q-5/SJ413V-5 (E01)
Samurai/SJ SJ410K-4 (E01) SJ410K
Samurai/SJ SJ410K-5/SJ410P-5 (E24)
Samurai/SJ SJ410K/SJ410P (E01:TYPE 1)
Samurai/SJ SJ410Q-5 (E01) SJ410Q
Samurai/SJ SJ410V-5 (E01) SJ410V
Samurai/SJ SJ413Q-6 (E24)
Samurai/SJ SJ413Q-7/SJ413V-7 (E01)
Samurai/SJ SJ413V-6 (E24)
Samurai/SJ SJ413W (E28)
Samurai/SJ SJ410/SJ410Q/SJ410V (E01:TYPE 2)
Samurai/SJ SJ413 (E03,E33:MY 1987) 87 MODEL
Samurai/SJ SJ410K (E01) SJ410K
Samurai/SJ SJ410K-4/SJ410P-4 (E24)
Samurai/SJ SJ413 (E03,E33:MY 1995) 95 MODEL
Samurai/SJ SJ413Q-6/SJ413V-6 (E01)
Samurai/SJ SJ410 (Santana)
Carry/Supercarry/Every SK410 (E01)
Samurai/SJ SJ410K (E28:MY 1983) SJ410K 83 MODEL

Samurai/SJ SJ410P SJ410P
Samurai/SJ SJ410P-2 SJ410P
Samurai/SJ SJ410W-3 (E01) SJ410W
Samurai/SJ SJ410W-4 (E01) SJ410W
Samurai/SJ SJ413-2 (E01)
Samurai/SJ SJ413K-2 (E01)
Samurai/SJ SJ413Q-5/SJ413V-5 (E24)
Samurai/SJ SJ410/SJ410Q (E28:MY 1982) 82 MODEL
Samurai/SJ SJ413 (E01)
Samurai/SJ SJ413 (E03,E33:MY 1992) 92 MODEL
Samurai/SJ SJ413W (E01)
Alto - A-Star/Celerio/800/Fronte SS80-3
Carry/Supercarry/Every ST90V-3 ST90V
Samurai/SJ SJ410/SJ410Q (E02,E06,E15,E16,E18,E19,E22,E25,E34,E39,E46,E54,E98)
Samurai/SJ SJ410W-3 (E24)
Samurai/SJ SJ413W (E24)
Carry/Supercarry/Every SK410-2 (E01)
Alto - A-Star/Celerio/800/Fronte SS80F-3/SS80AF-3
Carry/Every
Carry/Every
Carry/Every
Carry/Every
Carry/Every
Carry/Every
Carry/Every
Carry/Every
Jimny
Jimny
Jimny
Jimny
Jimny
Jimny

